www.venomuk.com
Venom Ltd. Solution House,
Sandon Road, Therfield, Hertfordshire SG8 9RE
Venom is a trademark of Venom Ltd.
sales@venomuk.com Helpline: +44 (0) 1763 284181

DESIGNED FOR SONY® PS3™

VX COMM'S FREEDOM HEADSET

USER GUIDE

Bluetooth™

User guide contents

1. **Introduction**
   1.1 Bluetooth wireless technology
2. **Getting started**
   2.1 Overview
   2.2 Chargers and batteries
   2.3 Switching the headset on and off
   2.4 Pair the headset with a compatible device (PS3™)
   2.5 Disconnect the headset from the device
   2.6 Reconnect the paired headset to your device
   2.7 Troubleshooting
3. **Basic use**
   3.1 Adjust the earphone volume
4. **Battery information**
5. **Care and maintenance**

Pack contents

- Bluetooth headset
- Mini USB charge cable.

1. Introduction

1.1 Bluetooth wireless technology

Thank you for purchasing the VX Comm's Freedom Headset. Bluetooth wireless technology makes it possible to connect compatible communication devices without using cables. A Bluetooth connection does not require that the device and the headset be in line of sight, but both devices should be within 10 metres (30 feet) of each other. Connections can be subject to interference from obstructions, such as walls or other electronic devices. The headset is compliant with Bluetooth specification 2.0 supporting the following profiles: headset profiles 1.1 and hands-free profiles 1.5. Check with the manufacturers of other devices to determine their compatibility with this device.

2. Getting started

2.1 Overview

The headset contains the following parts as shown in figure 1 on the next page. Before you can start using the headset, you must charge the battery and pair the headset with a compatible device.

Note: Parts of the headset are magnetic. Metallic materials may be attracted to the headset. Do not place credit cards or other magnetic storage media near the headset, because information stored on them may be erased.

Fig: 1

Key to figure 1

1. Indicator light
2. Volume up button
3. Power and synchronise button
4. Volume down button
5. Mini USB port

2.2 Chargers and batteries

The VX Comm's Freedom Headset is intended for use with the mini USB charge cable provided. This device has an internal, rechargeable battery. Connect the charge cable to the headset.

1. Connect the mini USB charge cable to your PS3™. The red indicator light is displayed during charging. If charging does not start, disconnect the charger, plug in again and retry. Charging the battery fully may take up to 2 hours.
2. When the battery is fully charged, the red indicator light will turn blue. Disconnect the charger from the mini USB outlet and the headset.

The fully charged battery has power for up to 8 hours of talk-time or up to 240 hours of standby time. However, the talk and standby times may vary when used with different devices, products that use a Bluetooth connection, usage settings, usage styles, and environments.
When the battery is running out of power, the red indicator light starts to flash.

2.3 Switching the headset on or off

To switch on, press and hold the power and synchronise button for 3 seconds. The blue indicator light starts to flash.
To switch off, press and hold the power key for 4 seconds until headset beeps once and the red indicator light is displayed briefly.

2.4 Pair the headset with a compatible device (PS3™)

1. Make sure your headset is turned off
2. Push the power and synchronise button

for 8 seconds until the blue and red light flash alternately.

3. On your PS3™ systems home menu, go to (Settings), then (Accessory Settings) and select (Manage Bluetooth Devices).
4. Select (Yes) to pair (Register) the headset with the PS3™ System.
5. Select (Start Scanning) The PS3™ System will then scan for all Bluetooth devices and then the devices will be displayed.
6. Select the headset (Venom) when prompted for the passcode enter 0000.
7. If the pairing is successful, the headsets blue light will flash 3 times briefly for the first time followed by a single flash every seven seconds.
8. Your headset is now paired with your PS3™ System.

2.5 Disconnect the headset from the device

To disconnect the headset from your device, do one of the following:

- Switch off the headset.
- Disconnect the headset in the Bluetooth menu of your device.
- Move the headset more than 10 metres (30 feet) away from the device.

You do not need to delete the pairing with the headset to disconnect it.

2.6 Reconnect the paired headset to your device

To connect the headset to your device, switch on the headset.

2.7 Troubleshooting

If you cannot connect the headset to your device, do as follows:

- Ensure that the headset is charged, switched on, paired with and connected to your device.
- Ensure that the Bluetooth feature is activated on your device.
- Check that the headset is within 10 metres (30 feet) of your device and that there are no obstructions between the headset and the device, such as walls or other electronic devices.

3. Basic use

3.1 Adjust the earphone volume

- *Volume up*. While in conversation, press the 'VOLUME(+)' button to increase the volume.
- *Volume down*. While in conversation, press the 'VOLUME(–)' button to decrease the volume.

4. Battery information

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three

complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out. Recharge your battery only with compatible chargers designated for this device.
Unplug the charge cable from your PS3™ when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.
Never use any charger that is damaged.
Do not leave device in hot or cold places as this will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15ºC and 25ºC (59ºF and 77ºF). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.
Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations. Please recycle where possible. Do not dispose as household waste.

5. Care and maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep all accessories and enhancements out of the reach of small children.
- Keep the device dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, allow it to dry completely.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not drop, knock or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the device.

All of the previous suggestions apply equally to your device, battery, charger or any enhancements.